



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
401002605	Heizkörper, 3000 W	Heating element, 3000 W	0401002605
401500530	Schalter, Ein - Aus, 16 A	Switch, on-off, 16 A	0401500530
401510001	Kontrolllampe	Indicator light	E0401500511
401520000	Mikroschalter	Microswitch	0401520000
402501501	Thermostat 30 - 110° C	Thermostat 30 - 110° C	0402501501
402511130	Sicherheitsthermostat 130 °C	Safety thermostat 130 °C	0402511130
402592130	Knebel 30 °C - 100 °C	Knob 30 °C - 100 °C	0402592130
402595000	Blending, Kunststoff	Blind ring, plastic	A0402595000
407800100	Griff f. Gehäuse	Handle f. housing	0407800100
407801500	Griff f. Deckel	Handle f. lid	0407801500
407810100	Fuß 12 x 4,5	Base 12 x 4,5	0407810100
408008002	Korb gross zu Nudelkocher 1322	Basket large f. pasta cooker 132260	132262
408703100	Verschraubung	Screw connection	0408703100
409081306	Unterlegscheibe 13 x 6 x 3	Flat washer 13 x 6 x 3	0409081306
450115100	Gehäuse	Housing	0450115100
450116500	Abdeckung	Cover	0450116500
450117000	Deckel	Lid	0450117000
450146000	Abdeckung f. Heizelement	Cover f. heating element	0450146000
450150050	Halterung f. Heizkörper	Bracket f. heating element	0450150050
450151500	Abdeckung	Cover	0450151500
450153100	Scharnier	Hinge	0450153100
452710004	Halterung z. Schaltkasten	Holder f. switch box	0452710004
500101560	Schaltkasten komplett	Switch box, complete	E0500101560
500105500	Paneel	Panel	0500105500
500111000	Becken	Basin	0500111000
500113500	Kabel m. Stecker	Cable m. plug	A0500113500
502520700	Abtropfsieb	Cullender	0502520700
509000200	Griff	Handle	0509000200
o. Abb./ no pic.	Kabel, blau	Cable, blue	E0402005005
	Kabel, rot	Cable, red	E0402006061

