

Bedienungsanleitung Elektroheizung für Chafing-Dish	D/A/CH
Instruction manual Electric heater for chafing-dish	GB/UK
Mode d'emploi Chauffage électrique pour réchaud "Chafing-Dish"	F/B/CH
Manuale di utilizzo Riscaldamento elettrico per Chafing Dish	I/CH
Mantenga las instrucciones Calentador eléctrico para calientaplatos	E
Manual de instruções Aquecedor eléctrico para o aquecedor de pratos	P
Bedieningshandleiding Elektrische verwarming loor Chafing dish	NL/B
Brugsanvisning skal El-varmelegeme til Chafing Dish	DK
Инструкция по эксплуатации Электроподогрев для мармитов	RUS
Kullanma kılavuzu Chafing Dish için elektrikli ısıtma	TR
Instrukcja obsługi Grzałka elektryczna do podgrzewaczy do potraw	PL
Návod k obsłużę Elektrické topení pro ohřívadlo na jídlo	CZ
Upute za upotrebu Električno grijanje za Chafing Dish	HR
Használati útmutató Villanyfûtés Chafing Dish-nek	Н
Οι οδηγίες χρήσης που ακολουθούν Ηλεκτρική θέρμανση για Chafing Dish	GR
Bruksanvisning Elektrovärmeelement	S





Technical data

Description	Electric heater for chafing dish (500.482, 500.486, 500.487)
Article no.	500.464
Materials:	Stainless steel
Voltage:	450 W / 220-230 V
Dimensions:	H 100-140 mm, Ø 135 mm
Weight:	1,5 kg

Subject to technical changes and alterations!



Before using this device

Please read this manual carefully <u>before</u> using the device. Check the device for any visual flaws. If any flaws or damages occur please contact customer support immediately.

Power cord and plug should not show any damages or flaws. If so, a qualified customer support is to be contacted without delay before the initiation.

Basic safety regulations

This purchased product conforms to the state-of-the-art and the acknowledged rules of technology, nevertheless dangers can occur. Please operate the electric heater only when in proper condition and under consideration of the user manual. The device is only to be used for its special purpose.

All technical interventions, as well as the installation and maintenance should only be done by qualified personnel. At non-compliance all of the manufacturer liabilities lapse.

Due to permanent technical improvement variations in operation can occur.



General notes

The device has been checked upon operability, however damages can occur from transportation. Please check the device upon soundness immediately after receipt.

We point out that the adherence of the accident prevention regulation is mandatory.

Operation instructions

- Heat up the device for about ten minutes before placing it under the chafing dish. Hereby a hard and moisture resistant layer is created on top of the heating surface. Do not be bothered by the temporary formation of smoke.
- As the bottom part's diameter is similar to that of a fuel paste container it fits perfectly into the gap or space where normally the fuel paste container is placed.
- Please make sure that the heating surface has a good contact to the cooking vessel and air circulation is adequate.
- o When filling hot water into the chafing dish only one electric heater is required.
- o Protect the enclosure (housing) against impacts and hits.
- o Touch and move the device only when it has cooled off.
- Do not pull the device at its feed cable.

Safety instructions

- Hot surfaces evolve from use. Be careful when touching the device or the cooking vessel because of the danger of burning yourself.
- Make sure to keep away the feed cable (of this and any other electric device) from the hot plate surface
- Do not move or carry around the device while it is in use dangers of scalding and burning
- Always place the device on level and non-slip surfaces
- As overheated fats and oils can be inflamed quite quickly the preparation of meals requiring these is only allowed under supervision.
- Never use the device unattended or with an empty food pan.

CAUTION!

- The unit is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the unit.
- Children should be observed to ensure that they are not playing with the unit.



- The device should be never left unattended during operation. Keep away children and other unqualified persons.
- Preserve this manual safely. When passing on/selling the device to a third party, the manuals must be handed over along with the device.
- Every person using the device must act in accordance to the manuals and under consideration of the safety advice.
- The device is to be used indoors only.
- The secure disconnection of the device occurs from pulling out the power plug.

Cleaning and maintenance

- Do not dunk the device into water for cleaning or similar purposes und 0 make sure that no steam or water can enter from beneath.
- If required the heating surface and the enclosure can be cleaned with a 0 damp cloth when chilled.

fax:

Waste disposal





For the disposal of the device please consider and act according to the national and local rules and regulations.

phone: +49 (0) 5258 971-0

+49 (0) 5258 971-120

Contact/Service address:

Bartscher GmbH Franz-Kleine-Straße 28 D-33154 Salzkotten Germany

- 9 -