



IT

MENSOLE RISCALDANTI - MANUALE ISTRUZIONE PER L'USO

EN


HEATED MIDDLE SHELVES - INSTRUCTION MANUAL

DE

WÄRMEBRÜCKE - BETRIEBSANLEITUNG

FR

ETAGERE CENTRALE CHAUFFANTE - MANUEL D'INSTALLATION



112081

112101

112122

112141

112161

112181

112201



ISTRUZIONI ORIGINALI/ORIGINAL INSTRUCTIONS/ORIGINALBETRIEBSANLEITUNG/INSTRUCTIONS ORIGINAUX


ATTENZIONE! prima di utilizzare l'apparecchio leggere attentamente le istruzioni

WARNING! read carefully the instructions before using the appliance


ACHTUNG! vor der Anwendung lesen Sie bitte aufmerksam die aufgeführten Hinweise

ATTENTION! avant d'utiliser l'appareil merci de lire les instructions

SCHEMA DI INSTALLAZIONE
INSTALLATION DIAGRAM
INSTALLATIONSPLAN
SCHEMA D'INSTALLATION



SCHEMA ELETTRICO
WIRING DIAGRAM
SCHALTPLAN
CABLAGE




1. INTRODUCTION
2. TECHNICAL DATA
3. INSTALLATION AND COMMISSIONING
4. MAIN RULES
5. USE OF THE APPLIANCE
6. DISPOSAL AND RECYCLING OF THE APPLIANCE

1. INTRODUCTION

This section shows the symbols and provides information about the model of the appliance, the various responsibilities and the copyright. It concerns heated middle shelf.

For further information refer to paragraph "Technical data" (2).

DATA PLATE



- The data plate shows the identification and technical data of the product.
- The data plate is inside the appliance on the right upper part of the heating panel.



WARNING!

- Do not remove, tamper with or erase the "CE" mark of the appliance.
- Refer to the data on the "CE" plate of the appliance in all communication with the Manufacturer (for example: when asking for spare parts, etc..)
- The "CE" plate has to be destroyed while scraping the appliance..

The present handbook is intended solely for consultation by the operator. Its content could be modified without notice. The Manufacturer reserves the right to stop the manufacturing of any model and/or introducing product changes but is not obliged to change products delivered before the modification and declines all responsibilities for any inaccuracy may appear on this handbook related to printing or translation mistakes.

The company cannot assume liability for damage and faulty operation due to:

- Failure to obey the instructions of this handbook;
- Modification or appliance alteration;
- Maintenance by unspecialized technicians ;
- Insufficient maintenance;

- Improper use of the appliance;
- Exceptional and unforeseeable events;
- Unrespect to domestic legislation on health, hygiene and safety at the workplace;
- The employer is responsible for the periodic training of the operators about the correct use, safety rules and fire prevention.

2. TECHNICAL DATA

RANGE OF HEATED MIDDLE SHELVES		2L	3L	4L
Supply voltage	V	220-240	220-240	220-240
Frequency	Hz	50-60	50-60	50-60
Max. power input	W	400	600	800
Max. current requirement	A	1,8	2,6	3,5
Power cord	Mmq-H05RN-F	3x1,5	3x1,5	3x1,5
Max. supply Voltage variation		+/- 10%	+/- 10%	+/- 10%
Max. Frequency variation	continuous	+/-1%	+/-1%	+/-1%
Max. Frequency variation	Short period	+/- 2%	+/- 2%	+/- 2%



WARNING!

- The electric power system and the rooms where the appliance is placed have to respect domestic legislation on safety, accident prevention and fire regulations. On the contrary the Manufacturer won't assume liability for direct and indirect damages to people or things.



3. INSTALLATION AND COMMISSIONING



WARNING!

- Intervention on the electric power system must be solely performed by specialized electricians.

Proceed according to the following instruction before connecting the appliance:

- Remove the packaging and then the protective film taking care not to scratch the surface;
- Make sure the power supply of the appliance shown on the data plate is compatible with the grid voltage;
- Check the power supply of the system is set up and able to take the current load, and meets the legal requirements and domestic standards;
- The appliance must be earthed;
- Plug the appliance. In case of direct connection to the electricity grid (without plug), it's necessary providing for a wall switch, which grants the complete disconnection according to overvoltage III rate and accordingly to installation rules;
- Have the system tested by a qualified electrician, if operation of the equipotential earth connection or the safety of the electrical system is in doubt, the symbol below identifies the equipotential connection:



The Manufacturer declines all responsibilities in case of connection made by the user or unspecialized staff



WARNING!

- After installation dispose of the packaging according to current regulations.

This appliance is designed and optimized to ensure high performance and efficiency. The sole use of this appliance is keeping food heated.

**WARNING!**

- Contact with hot tableware can cause burns.
- Use always suitable safety equipment while handling objects.


4. MAIN RULES

The Manufacturer does not assume responsibility for faults or damage due to tampering the appliance. This appliance must be used by skilled persons that must be periodically trained for its correct use and according to the safety regulations and prevention of accidents. Contact with hot tableware in the appliance can cause health risks. In order to prevent them use safety equipment and act with suitable caution.

**WARNING!**

- Intervention on the electric power system must be solely performed by specialized electricians.

5. USE OF THE APPLIANCE



Press the main switch on the supply panel that powers the appliance.

Switch on the button "A" to position "I". When the button "A" is switched on, it is lighted up and the appliance is under power and starts operating.

To stop heating turn the switch to "O" position. The heating is so disconnected but the appliance is under power.

Avoid amassing plates and place them under the lights.

Switch off finally the main power supply line ahead of the appliance or plug the appliance off.

Only when the appliance is disconnected, clean the stainless steel surfaces with warm water and a neutral soap, rinse thoroughly and dry carefully.

In case of long period of inactivity, store the appliance in a dry place.



6. DISPOSAL AND RECYCLING

Dispose of the appliance responsibly and respect the environment at the end of its useful life. Proceed with its disposal in accordance with domestic regulation.